



Autometer Speedometer calibration procedure for all 02 to 04 Gilroy Indians.

The procedure is as follows:

1. Ride the bike to a place where you can have 2 miles of uninterrupted riding.
2. Once you are at the mile marker, shut the bike off with the ignition key.
3. Hold down the odometer button and turn the ignition key on at the same time.
 - a). With the ignition still on:
4. Press the same odometer button again. You will see O_ _ _ _ _O in the odometer display.
5. Start the bike up and ride it for 2 miles at 45 mph. (very important to keep the speed at 45 mph during this procedure). **Note the speedometer will not be operational at this time, so have another rider in front of you to gage your speed or use a cell phone speedometer app.**
6. At the end of the 2 mile run, pull over safely to the side of the road. Leave the engine running and press the odometer button again. You should see numbers in the odometer display (example 16575). This related to the number of pulses that the transmission sensor has recorded to the speedometer.
7. Next, turn the engine off. Then restart the engine and now the speedometer will operate and the odometer miles will display as normal.
8. You have now calibrated the speedometer.